



Professional Flaring Tool – Item 17515

1. Loosen two wing nuts on flaring tool bar and separate bars.
2. Insert tubing into proper size hole and close flaring bars. Make sure tube extends 1/8" beyond the top of the flaring bar, then tighten wing nuts.
3. Slip yoke onto flaring tool bar then position yoke over end of tube.
4. Turn yoke handle to flare tube end. A flare is complete when yoke handle cannot be turned any more.
5. Loosen yoke handle. Remove yoke from bars and loosen both wing nuts before attempting to remove tubing.

 **WARNING:** This packaging can expose you to chemicals including Vinyl Chloride, which is known to the State of California to cause cancer. For more information, go to www.P65Warnings.ca.gov.

 **ADVERTENCIA:** Este embalaje puede exponerle a químicos, incluyendo cloruro de vinilo, que es conocido por el Estado de California como causante de cáncer. Para mayor información, visite www.P65Warnings.ca.gov.

 **AVERTISSEMENT:** Ce emballage peut vous exposer à des agents chimiques, y compris chlorure de vinyle, identifiés par l'Etat de California comme pouvant causer le cancer. Pour de plus amples informations, prière de consulter www.P65Warnings.ca.gov.



Superior Tool®

Naperville, IL 60563

superiortool.com

© 2023 Superior Tool Company