

SuperRing® - Closet Flange Repair Ring Item 21015

For Solvent Welded Steel/Plastic Combo and Plastic Closet Flanges:

If possible, remove remaining portion of corroded and broken flange. If remaining portion cannot be removed, SuperRing will be mounted on top. Apply a small bead of RTV silicone sealant to the underside of the SuperRing that will mount on top of old flange. Set SuperRing on top of remaining portion of old flange. Note old location, if possible, of old toilet bolt slots. The length of the bolt slots in the SuperRing allows for some centering of toilet. Secure the SuperRing to wood or concrete subfloor with screws and/or anchors.

For Cast Iron Flanges:

SuperRing can be mounted directly on top of an old cast iron closet flange. Drill holes in any remaining portion of cast iron flange that corresponds with holes in SuperRing. Apply bead of RTV silicone sealant to underside of SuperRing. Large gaps or spaces around or underneath the closet ring can be filled with any quick setting type grouts, cements, etc.

Please Note:

When setting toilet, use a wax bowl ring with plastic flange for best performance.



ADVERTENCIA: Este embalaje puede exponerle a químicos, incluyendo cloruro de vinilo, que es conocido por el Estado de California como causante de cáncer. Para mayor información, visite www.P65Warnings.ca.gov.

AVERTISSEMENT: Ce emballage peut vous exposer à des agents chimiques, y compris chlorure de vinyle, identifiés par l'État de California comme pouvant causer le cancer. Pour de plus amples informations, prière de consulter www.P65Warnings.ca.gov.

