


2"Soft Grip Ratcheting PVC Cutter – Item 37116


Blade Replacement:

CAUTION! SHARP BLADE!

1. Remove the pivot screw and pivot pin.
2. Carefully remove the old blade and re-install the new one.
3. Re-install the pivot pin and tighten the pivot screw.
4. Properly dispose of the old blade.

 **WARNING:** This packaging can expose you to chemicals including Vinyl Chloride, which is known to the State of California to cause cancer. For more information, go to www.P65Warnings.ca.gov.

 **ADVERTENCIA:** Este embalaje puede exponerle a químicos, incluyendo cloruro de vinilo, que es conocido por el Estado de California como causante de cáncer. Para mayor información, visite www.P65Warnings.ca.gov.

 **AVERTISSEMENT:** Ce emballage peut vous exposer à des agents chimiques, y compris chlorure de vinyle, identifiés par l'Etat de California comme pouvant causer le cancer. Pour de plus amples informations, prière de consulter www.P65Warnings.ca.gov.



Superior Tool®

Naperville, IL 60563

superiortool.com

© 2023 Superior Tool Company