



## DrainKey™- Item 4500

- Place the DrainKey inside the drain.
- Hold the large hex nut with your hand and begin turning the threaded screw clockwise until it is snug in the drain.
- Grip the hex nut with a wrench or channel lock pliers while turning the threaded screw clockwise with another wrench — this will lock the three knurled "shoes" into the drain as well as locking the screw and nut together. It is very important that the hex nut, screw and the three knurled shoes are locked firmly inside the drain.
- Once the DrainKey is secure inside the drain, begin by only turning the hex nut counterclockwise until the drain breaks free.
- Note: if the tool slips or starts to unscrew itself in the drain it has not been tightened enough.
- Once the drain is removed, turn the screw counterclockwise with a wrench while holding the hex nut with a wrench to release the DrainKey.

 **WARNING:** This packaging can expose you to chemicals including Vinyl Chloride, which is known to the State of California to cause cancer. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

 **ADVERTENCIA:** Este embalaje puede exponerle a químicos, incluyendo cloruro de vinilo, que es conocido por el Estado de California como causante de cáncer. Para mayor información, visite [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

 **AVERTISSEMENT:** Ce emballage peut vous exposer à des agents chimiques, y compris chlorure de vinyle, identifiés par l'Etat de California comme pouvant causer le cancer. Pour de plus amples informations, prière de consulter [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).



**Superior Tool®**

Naperville, IL 60563

[superiortool.com](http://superiortool.com)

© 2023 Superior Tool Company